

BBU FAQ

Q: How do I turn-on the batter or turn-off the battery?

A: Press and hold the *Function* button for about 3 seconds

Q: How do I turn on the flash light or strobe?

A: Press-and-release the *Function* button to toggle between hi-beam, fast strobe and SOS.

Q: How do I know when the battery is fully charged?

A: All 4 LEDs will glow steadily.

Q: How do I know when the battery is charging?

A: 1-3 LEDs will flash while charging.

Q: What do I do if only the far left LED is flashing?

A: This is an indication of a thermal sensor error. Remove the battery and replace it. Call your local Guardian dealer for a replacement battery.

Q: What do I do if ONLY the two LEDs on the left are flashing?

A: This is an indication that the BBU has reached a high temperature extreme (>140°F) and the thermal protection has activated. The BBU will return to normal when no longer exceeding temperature extremes. No action is required unless the BBU does not recover. If the BBU does not recover turn-off the BBU power and replace.

Q: What do I do if ONLY the two LEDs on the right are flashing?

A: This is an indication that the BBU has reached a low temperature extreme (<14°F) and the thermal protection has activated. The BBU will return to normal when no longer exceeding temperature extremes. No action is required unless the BBU does not recover. If the BBU does not recover turn-off the BBU power and replace. Call your local Guardian dealer for a replacement battery.

Q: What do I do if ONLY the two LEDs on the right are flashing?

A: This is an indication that the BBU has reached a low temperature extreme (<14°F) and the thermal protection has activated. The BBU will return to normal when no longer exceeding temperature extremes. No action is required unless the BBU does not recover. If the BBU does not recover turn-off the BBU power and replace. Call your local Guardian dealer for a replacement battery.

Q: What do I do if all four LEDs are flashing?

A: This is an indication that the *kill switch* has been triggered. Remove the battery from the holster, turn off the battery and replace the battery. Call your local Guardian dealer for a replacement battery.

Q: What is the purpose of the connector under the rubber cover?

A: An installation cable can be connected to the BBU. This enables the installer to program the 715BBU without mains power.

Q: What do I need to charge the BBU outside of the holster?

A: Purchase a DC15V/1A transformer or DC12V cigarette light adapter with a 3.5mm jack from your local electronics supply store.

Q: Why don't the holster LEDs illuminate when I open or close the door?

A: Under AC power, when ambient light is low, the LEDs simply act as a motion-sensing light to provide some illumination when walking a dark garage. During a power outage, it acts as courtesy light upon door opener operation.